HP Deskjet F4480 Lid Panel Removal

Removing the back panel of the printer cover allows access to the Scanner Light and the Glass Screen.

Written By: Tim



TOOLS:

- T10 Torx Screwdriver (1)

Step 1 — Remove Back Panel of Lid



- Remove one 9mm T10 Torx screw from the back of the printer lid.

Step 2






- Press outward on the plastic tab holding the back panel in place.

Step 3





- Pull the back panel towards you and lift it away from the rest of the printer cover.

⚠ Some ribbon cables may still be inserted through the back panel. Be careful not to damage these and they should slide out easily.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-25 09:41:39 PM.